

RAZBAM FLIGHT MANUAL
NAVY MODELS

RAZAIR-01-60GAB-1



T-2A T-2B
T-2C T-2D T-2E

Buckeye Aircraft



RAZBAM FLIGHT MANUAL
NAVY MODELS
T-2A, T-2B, T-2C, T-2D & T-2E
BUCKEYE AIRCRAFT

RAZAIR 01 60GAB 1



INTRODUCTION

Thank you for your purchase of RAZBAM's North American/Republic T-2 Buckeye aircraft model. We at RAZBAM have worked to deliver to you the most accurate model of this fascinating aircraft and we promise you that you will enjoy flying it.

The T-2 Buckeye is a two place subsonic trainer, powered by two axial flow turbojets (In the case of the T-2J 1 S also designated as the T-2A the aircraft is powered by a single turbojet. The Buckeye was well designed for field maintenance conditions, with serviceable components installed at waist level or lower. Thus, the need for stands and ladders for most routine maintenance, including fueling, was eliminated. While training more than 11,000 student pilots to fly 18 different models of Navy jet aircraft, the Buckeye established an outstanding record of safety and reliability for many years, but as the machine has aged it has developed some problems, being grounded for safety reasons three times in 1997 alone. After 41 years of service, the North American T-2 "Buckeye" jet trainer was phased out, in favor of the Boeing/BAE T 45A "Goshawk."

The package that you have purchased contains the following models: T-2A (T-2J 1 S), T-2B, T-2C used by the U.S. Navy and U.S.M.C., the T-2E used by the Venezuelan Air Force (Fuerza Aérea Venezolana) and the T-2E used by the Hellenic Air Force (Πολεμική Αεροπορία). All models can load weapons. The T-2D and T-2E have been modeled with the Armament Kit that added another two hard points in the wings.


CONTROL CONFIGURATION

Since the T-2 Buckeye is a military airplane capable of dropping ordnance the following controls must be mapped.

Weapons Release (Trigger)

The airplane armament release function is dependent on the setting of certain switches. Unfortunately FSX does not provide support for that feature. In order to be able to drop ordnance in both free flight and missions the following key map must be used:

Joystick Button 01: Cabin alert – Seatbelts (on/off).
(See figure below)



If you do not have a joystick, set any keyboard combination to this event.

Note: The default keyboard combination for dropping objects still works in missions, but it won't trigger the weapons animation.



SWITCHES NAVIGATION

The T-2's cockpit instruments have several types of switches, pushbuttons, knobs and levers. Usually you only have to click with your left mouse button on the switch to have it change its position, but there are several that have multiple positions that move back and forth. For these multiple position switches and knobs you have to left click to go forward and right click to go backwards.

The following is a chart of the different switches and knobs found on the cockpit and how to navigate them.

Switch Type Navigation


Switch	Type	Navigation
	2-Position Switch	Left-Click changes the position.
	3-Position Switch	Left-Click moves forward. Right-Click moves backwards. <i>Example:</i> Left-Click: BOTH OFF UPPER. Right-Click: UPPER OFF BOTH.
	Multi position Knob	Left-Click moves forward. Right-Click moves backwards.
	Pushbutton	Left-Click changes the position.
	Thumbwheel	Left-Click moves forward. Right-Click moves backwards. Center wheel moves forward fast.
	Rotating	Knob Left-Click moves forward. Right-Click moves backwards. Center when moves both forward and backwards faster.

AIRCRAFT

The T-2 Buckeye is a two place subsonic trainer.

Note: The information detailed below applies to all versions of the T-2 unless otherwise specified. All gauges and instruments detailed in this manual are fully operational unless otherwise specified.

PRINCIPAL DIMENSIONS



Dimension		Weight		Fuel	
Length	38' 8"	Empty Weight	8,115 lbs	Fuselage	387 gallons
Wingspan	38' 2"	Max Takeoff	13,180 lbs	Wing tips	102 gallons
Height	14' 9"				
Wing area	255 ft ²				

Engine

The T-2A (T-2J-1-S) was powered by a single Westinghouse J34-WE-46/48 turbojet with 3,100 pounds of thrust. The T-2B was powered by two Pratt & Whitney J60-P-6 with 2,905 pounds of thrust each. The T-2C, D and E versions were powered by two General Electric J85-GE-4 turbojets with 2,950 pounds of thrust.



INSTRUMENTS PANEL

T-2A (T-2J-1-S)



T-2B




Main Instrument Panel
(Front and Rear cockpits)



Lateral Consoles
(Front and Rear cockpits)

Main Instrument Panel
(Front and Rear cockpits)



Lateral Consoles
(Front and Rear cockpits)



T-2C, T-2D & T-2E



Main Instrument Panel
(Front and Rear cockpits)



Lateral Consoles
(Front and Rear cockpits)





ENGINE CONTROLS

Exhaust Gas Temperature Indicators.

The EGT indicators, one for the T-2A and two for the other versions, display each engine exhaust gas temperature in degrees centigrade (°C)

Note: Engine damage is possible during overtemperature condition. See Operational Limits Section.



PT5 Pressure Indicators

The engine PT5 pressure indicators indicate from 0 to 90 inches Hg engine turbine discharge total pressure. The pressure readings from these indicators are used to determine takeoff power of the engine under any altitude or atmospheric conditions.

There is a single indicator with two needles, one for each engine. The T-2A has a single needle.



Oil Pressure Indicators.

The engine oil pressure indicators are calibrated from 0 to 10 (x10) psi.

There is a single indicator with two needles, one for each engine. The T-2A gauge has a single needle.



Tachometers.

The tachometers provide an indication of each engine's rotation speed in percent of rpm. Each tachometer dial has two pointers that indicate in percent of rpm with reference to two separate scales. The smaller pointer rotates in a scale to indicate from 0 to 10 % rpm. The larger pointer rotates on a larger scale and indicates from 0 to 120 % rpm.

Each engine has its own tachometer (only one for the T-2A).



Fuel Flow Indicator.

The fuel flow indicator displays the rate of fuel consumption of each engine. The indicators are scaled from 0 to 5 (X1000) pounds per hour.


The indicator has a single dial with two needles, one for each engine. The T-2A has a single needle.






The T-2 Buckeye has an Engine Control Panel located on top of the Throttle Quadrant. Here you can start the engine and shut it down as needed.

T-2A (T-2J-1-S)
Engine Control Panel



T-2B, T-2C,
T-2D & T-2E
Engine Control Panel



ENGINE MASTER Switch

The engine master switches (there is only one in the T-2A) control the fuel shut off valve for each engine. They must be in the ON position for the engine to be used.

ENGINE STARTER Switch

The engine STARTER switch initiates the starting cycle. Left clicking on it will place it on the START position and the engine start sequence will begin. **All versions except T-2A:** Right clicking will place the switch on the STOP position and will cancel the engine start sequence. Releasing the mouse button will return the switch to the OFF position.

Note: For all versions except the T-2A, the ENGINE START sequence will begin only if the aircraft is on the ground.

ENGINE AIRSTART Switch (Not available in the T-2A)

The engine airstart switch will initiate the engine starting cycle.

The start sequence will initiate with the aircraft either in the ground or in the air. The switches are covered to prevent damage to the igniters and should remain OFF.

ENGINE START SEQUENCE PROCEDURE

To start the engines proceed as follows:

1. Click the MASTER ENGINE switch to the ON position.
2. Click on the ENGINE START switch. The sequence will begin.

Repeat the sequence for the No. 2 Engine

Not applicable to the T-2A

NOTE: Either engine can be started first.



FUEL CONTROLS



Fuel Quantity Indicator

The fuel indicator only provides fuel quantity information for the main fuselage tank.

Tip tank fuel quantity status is not provided, but exhaustion is indicated when the needle starts decreasing.

The indicator is calibrated to indicate tank level in pounds (X100) to a maximum of 2,900 pounds.

Note: Due to FSX limitations, the tanks are identified by the simulator as follows:

- Fuselage Tank: Center 1
- Left Tip Tank: LeftTip
- Right Tip Tank: RightTip



FUEL DUMP Handle

The fuel dump handle opens the tip tanks fuel dump valves. Fuel dumping can be stopped at any time by clicking on the handle to close the valves.

NOTE: The fuel dump valves can only be opened while on flight. Only the tip tanks fuel will be dumped.



T-2A (T-2J-1-S)
Electrical Panel Location

ELECTRICAL SYSTEM CONTROLS

T-2A (T-2J-1-S)

DC POWER Switch

The **DC POWER switch** is a three position lever lock type of switch that controls power distribution to the aircraft.

BAT & GEN: This is the normal condition during flight.

OFF: Both Master Battery and engine generator are disconnected (Default if aircraft is parked with the engine off).

BAT ONLY: This position connects the main battery only.

INST AC PWR Switch

The **INSTRUMENT A C POWER** switch controls which **Inverter** provides power to the instruments. Default position is **No. 1 INV.**

GEN RESET Switch

The **GENERATOR RESET** switch restarts the engine generator if it goes offline (the No. 1 GEN OUT caution light will illuminate). It will return to the OFF position when you release the left mouse button.





CONTROL TRANS Switch

The electrical control transfer switch transfers electrical control from the front cockpit to the rear one. The switch will return to the OFF position when you release the left mouse button.

T-2B, T-2C, T-2D & T-2E

BATTERY Switch

Connects/Disconnects the **Master Battery**.

INSTR AC PWR Switch


The **INSTRUMENT AC POWER** switch controls which Inverter provides power to the instruments. Default position is **No. 1 INV.**

No. 1 & No. 2 GEN Switches

Connects/Disconnects the engine generators.

CONTROL TRANSFER Switch

The electrical control transfer switch transfer electrical control from the front cockpit to the rear one. The switch will return to the OFF position when you release the left mouse button.



VOLTMETERS

A combination voltmeter and ammeter is mounted on each subpanel, right and left of the instrument panel. One for each generator.

NOTE: For the T-2A (T-2J-1-S) both gauges will show the readings for the same generator.



T-2B
Electrical Panel Location



T-2C/D/E
Electrical Panel Location



We hit several FSX limitations while implementing this panel. One of them is the way that FSX distributes electrical power to all subsystems, so we were unable to precisely simulate all the T-2's real electrical subsystems.



FLIGHT AND TRIM CONTROLS AND SYSTEMS

All trim tabs for aileron and elevators are actuated by buttons on the control stick. These buttons are inoperative in all models. Please use the FSX default keys for trim selection. There is a simple TRIM panel located just below the throttle.

T-2A (T-2J-1-S)



RUDDER TRIM Switch

The rudder trim switch controls the rudder position.

Left Click will trim to the left.

Right Click will trim to the right.

NOTE: Every time you release the mouse button, the switch will center, but the rudder will remain in the trim position that you selected.

There is no rudder auto center function in the TRIM panel.

TAKE OFF TRIM Indicator

It indicates if the elevator trim is centered or not.

IN: Indicates DOWN trim.

OUT: indicates UP trim

The blue on white stripes indicates that the elevator trim is centered.

T-2B, T-2C, T-2D & T-2E



RUDDER TRIM Switch

The rudder trim switch controls the rudder position.

Left Click will trim to the left.

Right Click will trim to the right.

NOTE: Every time you release the mouse button, the switch will center, but the rudder will remain in the trim position that you selected.

There is no rudder auto center function in the TRIM panel.

AIL & RUD TRIM Indicators

These indicators show if either the ailerons or the rudder are trimmed. A green light will show when they are centered.

ELEV TRIM Indicator

The elevator trim indicator is graduated in nose up and nose down units (degrees) of elevator trim.



FLAP SYSTEM

The T-2 has trailing edge flaps that have a maximum of 33 degrees extension.

FLAP HANDLE

The FLAP handle is located besides the Throttles handles in all models. The FLAP handle has three positions only: UP, HALF and DOWN with no intermediate positions. To activate the flap handle you must click on it and drag the mouse.



T-2A (T-2J-1-S) Flap Handle

T-2B, T-2C, T-2D & T-2E Flap Handle

WING FLAP POSITION Indicator

A wing flap position indicator is integrated with the gear position indicator on each instrument panel. The indicator is calibrated for the UP, 1/4, 1/2, 3/4 and DOWN positions. The aircraft only uses the UP, 1/2 and DOWN positions.



The WING FLAP Indicator positions (UP, HALF, DOWN).

SPEED BRAKE SYSTEM

Two speed brakes are provided: one on each side of the aft fuselage forward of the arresting hook.

SPEED BRAKE Switch

A speed brake switch is mounted in the inboard throttle handle (on top of the throttle handle for the T-2A). This button is inoperative in the model due to the difficulty to reach them while flying. Please use the key mapped for the SPOILERS.



SPEED BRAKE indicator.

The speed brake indicator is installed in each instrument panel adjacent to the landing gear handle. When the speed brakes are in and locked the word IN will appear within the indicator. With the speed brakes full out, the indicator will read OUT. At an intermediate speed brake position, the indicator will show a barber pole.

SPEED BRAKE DUMP Handle

The speed brake dump handle allows for closing the speed brake.





LANDING GEAR SYSTEM

The tricycle landing gear consists of an aft retracting nose gear and a forward retracting main gear. Dual nose gear wheels are independently mounted on a common axle. Catapulting provisions are built into the nose gear. The landing gear position indicators are operated by the landing gear.

Landing Gear Handle


A landing gear handle is located to the left of the instrument panel in each cockpit.

Landing Gear Position Indicators

A landing gear position indicator is located on each instrument panel and is integrated with the wing flap position indicator. Three "flip flop" indicators in separate windows provide visual indication of landing gear position. When the landing gear is up and locked, the word "UP" appears in each window. A barber pole appears when the landing gear is in intermediate position. When the landing gear is down and locked, tire treads are shown.



UP - In Transition - DOWN



WHEELS Warning light.

The WHEELS warning light will turn on when the following conditions are met:

1. Engine % RPM is below 92%
2. FLAPS are UP.
3. Landing Gear is not fully extended.

WHEEL BRAKE SYSTEM

The aircraft contains a wheel brake system. Normal braking is obtained by pressing the assigned keyboard combination (default is the "." key).


CATAPULTING SYSTEM

The T-2 has a catapulting equipment consisting of two catapult hooks attached to the forward underside of the fuselage (see figure below).



Installation or removal of the launch bar is accomplished by pressing the assigned keyboard combination (default is "Ctrl+I").

ARRESTING HOOK SYSTEM



The aircraft has an arresting hook for use with an arresting cable system, both for carrier operations and for short landing operations. The arresting hook is externally mounted below the aft section of the fuselage.

The arresting hook can be extended or retracted by clicking on the arresting hook handle or by pressing the assigned keyboard combination (default is "Shift+Q").

ARRESTING HOOK Handle.

An ARRESTING HOOK handle is located on the right side of the instrument panel in each cockpit.

To lower/raise the arresting hook, you only need to click on it.



AIR CONDITIONING AND PRESSURIZATION SYSTEM

The aircraft has an air conditioning and cockpit pressurization system. Only the cockpit pressurization system has been implemented. Cockpit altitude is shown in a cockpit pressure altimeter on both instruments panels.



CABIN PRESSURE Altimeter.

The cockpit is unpressurized from sea level to 8,000 feet. From 8,000 feet to 23,400 feet the regulator maintains a cockpit pressure equivalent to 8,000 feet. Above 23,000 feet, the regulator maintains a 5.0 psi pressure differential between cockpit and flight altitude pressures. At flight altitude of 50,000 feet, the cockpit pressure is about 20,000 feet.

T-2A (T-2J-1-S)



Location of the Panel



Cockpit Pressurization and Air Conditioning Control Panel



T-2B



T-2C, T-2D & T-2E

T-2B, T-2C, T-2D & T-2E

COCKPIT PRESSURE Switch (PRESSURE).

The cockpit pressure switch is a two position toggle switch which controls the position of the main system shutoff valve. Cockpit pressure is automatically maintained.

COCKPIT TEMPERATURE Switch (TEMP).

The cockpit temperature switch is a three position toggle switch. It operates in conjunction with the windshield anti ice and canopy defrost switches.

SUPPLY TEMPERATURE Rheostat (SUPPLY TEMP).

The supply temperature rheostat provides automatic control of the cockpit temperature.

WINDSHIELD ANTI ICE Switch (Not Pictured).

The windshield anti ice and rain removal switch is a two position toggle switch which controls the anti ice and rain removal system.

WINDSHIELD ANTI ICE OVERHEAT Caution Light.

The windshield anti ice overheat caution light turns on if the air temperature in front of the windshield rises above 315° F.

WINDSHIELD AND CANOPY DEFROST Switch.

A windshield/canopy defrost switch is located in each cockpit.



Cockpit Press Control Panel



INTERIOR AND EXTERIOR LIGHTS

INTERIOR LIGHTS

The interior lighting system consists of flight and non flight instrument panel lights and console lights. They can be independently turned on and off by clicking on their respective switches.

CONSOLE LIGHTS Switch

The CONSOLE lights switch turns on/off the console and instruments panel edge lighting.

INSTRUMENTS LIGHTS Switch

The INSTRUMENTS lights switch turns on/off the lights of each individual instrument.



T-2A



T-2B



T-2C, T-2D & T-2E



T-2A



T-2B



T-2C, T-2D & T-2E

EXTERIOR LIGHTS

The exterior lighting system consists of Anti Collision (at the top and bottom of the fuselage), Formation (fuselage and wings), Wing (wing tips) and Tail lights. Each exterior light is independent from each other.

Formation (FORM) Lights Switch

The Formation Lights switch controls the illumination of the tip tank and fuselage formation lights.

WING Lights Switch

The WING lights switch controls illumination of the tip tanks position lights.

TAIL Lights Switch

The TAIL lights switch controls the tail lights.

ANTICOLLISION Lights Switch

The ANTICOLLISION lights switch controls both anticollision beacons.






WARNING, CAUTION AND ADVISORY LIGHTS

Abnormal operation conditions of any of the aircraft systems are alerted to the pilot by means of caution lights. Most caution lights are grouped on the instrument panels as an aid in monitoring.

Caution Lights.



Caution Lights Panel location



T-2A



T-2B



T-2C, T-2D & T-2E



Caution Light	Malfunction or Abnormal Condition
LOW FUEL	Turns on when the fuel remaining in the main fuselage tank is below 605 pounds
No. 1 GEN OUT	Turns on when the engine 1 generator is offline.
No. 2 GEN OUT	Turns on when the engine 2 generator is offline (Does not apply to T-2A)
ENG. 1 FIRE COMPRESSOR	Turns on when the engine 1 is on fire
ENG. 1 FIRE BURNER	Turns on when the engine 1 is on fire
ENG. 2 FIRE COMPRESSOR	Turns on when the engine 2 is on fire (Does not apply to T-2A)
ENG. 2 FIRE BURNER	Turns on when the engine 2 is on fire (Does not apply to T-2A)
OXYGEN	Turns on when Oxygen remaining falls below 1 pound.
INSTRUMENT POWER OFF	Turns on when electrical power to the instrument panel is off.
CANOPY UNLOCKED	Turns on when the canopy is not closed and locked.
WINDSHIELD ANTI ICE OVERHEAT	Turns on when the Windshield Anti Ice switch is ON and the air temperature in the windshield is above 315° F
FUEL FILTER NON Functional	Turns on only when the TEST LIGHT switch is ON.
HYD BOOST OFF	Turns on when the electrical hydraulic pump is off.
OBTAIN COURSE AFT COCKPIT	Turns on when the TACAN CONTROL Switch is ON (TACAN is being controlled by the aft cockpit).


The Annunciator Lights can be tested by clicking on the TEST LIGHTS switch that is in the ELEC PANEL (Please see the figure in the ELECTRICAL SYSTEM section). The TEST LIGHTS switch is a three position toggle switch. Left clicking will test the main annunciator panel lights. Right clicking will test the ENGINE FIRE lights. The switch will return to the center position when the mouse button is released.



OXYGEN SYSTEM

There is a working oxygen supply system ready to be used for missions. The system uses 10 liters of liquid oxygen which converts into 860 liters of gaseous oxygen. Oxygen flow depends on altitude, at higher altitude the lower the flow. The oxygen flow can be mixed with cockpit air to allow for more endurance (see attached Oxygen Duration Chart).

GAGE QUANTITY-LITERS

COCKPIT ALTITUDE ~ FEET	GAGE QUANTITY-LITERS										LESS THAN 1 LITER
	10	9	8	7	6	5	4	3	2	1	
35,000 AND ABOVE	16.1	14.5	12.8	11.2	9.6	8.0	6.4	4.8	3.2	1.6	 DESCEND TO AIRCRAFT ALTITUDE NOT REQUIRING OXYGEN WHEN OXYGEN WARNING LIGHT ILLUMINATES (BELOW 0.9 LITER OR PRESSURE BELOW 45 PSI)
30,000	12.7	11.4	10.2	8.9	7.6	6.3	5.1	3.8	2.5	1.2	
25,000	10.2	9.2	8.1	7.1	6.1	5.1	4.0	3.0	2.0	1.0	
20,000	8.2	7.4	6.6	5.7	4.9	4.1	3.3	2.4	1.6	0.8	
15,000	6.7	6.0	5.3	4.7	4.0	3.3	2.6	2.0	1.3	0.6	
10,000	5.5	4.9	4.4	3.8	3.3	2.7	2.2	1.6	1.1	0.5	
5,000	4.4	4.0	3.6	3.1	2.6	2.2	1.7	1.3	0.8	0.4	
SEA LEVEL	3.7	3.4	3.0	2.6	2.2	1.8	1.5	1.1	0.7	0.3	

MAN-HOURS REMAINING AT 100% OXYGEN

- TABLE BASED ON 100 PERCENT OXYGEN CONSUMPTION BY TWO CREW MEMBERS. OXYGEN DURATION IS DOUBLED WHEN AIRCRAFT IS FLOWN SOLO.
- DATA BASED ON COMPLETE OXYGEN DEPLETION.

Note: Because there is less ambient pressure acting upon the lungs at altitude, a lesser quantity of oxygen will expand the lungs to their normal size. Therefore, oxygen duration increases as cockpit altitude increases.

ANGLE OF ATTACK SYSTEM

The angle of attack indicating system and the approach lights provide the pilot with visual indications of angle of attack. Indications are presented on the angle of attack indicator under all flight conditions and may be used to establish various flight altitudes. For convenience in controlling airspeed in landing approaches, indicator readings are supplemented by lights on the angle of attack indexer mounted on the windshield frame.

ANGLE OF ATTACK INDICATIONS

SLOW
 Approach speed more than 5 knots slow. Nose-down correction needed.
 16.4 units or more
 Upper chevron lighted. Pointer at or above upper edge of approach index marker.

MODERATELY SLOW
 Approach speed 3 to 5 knots slow. Slight nose-down correction needed.
 15.3 to 16.4 units
 Upper chevron and circle lighted. Pointer just above center of approach index marker.

OPTIMUM
 Angle of attack and approach speed at optimum. No correction needed.
 15.0 ± 0.3 units
 Circle lighted. Pointer near center of approach index marker.

MODERATELY FAST
 Approach speed 3 to 5 knots fast. Slight nose-up correction needed.
 14.7 to 13.6 units
 Lower chevron and circle lighted. Pointer just below center of approach index marker.

FAST
 Approach speed more than 5 knots fast. Nose-up correction needed.
 13.6 units or less
 Lower chevron lighted. Pointer at or below lower edge of approach index marker.



FLIGHT INSTRUMENTS



Altimeter

The counter/pointer altimeter indicates aircraft altitude in the atmosphere in thousands and hundreds of feet. The single sweep hand indicates altitude in hundreds of feet. The counter has three drums which rotate to indicate altitude to a maximum of 90,000 feet. At altitudes below 10,000 feet the leftmost digit will show a barber pole. The pilot must multiply the value indicated in the counter by 100 to get the aircraft altitude.

The four digit counter in the bottom of the dial indicates the altimeter barometric setting (Kohlsman setting). The value can be changed by clicking on the knob in the lower left.



Airspeed Indicator

The airspeed indicator consists of two movable pointers and a Mach number window.

The plain pointer indicates current aircraft indicated airspeed. The stripped pointer (not shown) indicates maximum allowable airspeed. This pointer indication fluctuates depending on the aircraft altitude. At higher altitudes, the lower the max speed. The Mach number window indicates the current Mach number.



Attitude Indicator

The Attitude Indicator displays the relation of the aircraft attitude about the pitch and roll axes to the horizontal plane of the earth.



Vertical Speed Indicator (VSI)

The VSI show the rate of change of altitude. Positive values indicate that the aircraft is climbing. Negative values indicate that the aircraft is diving.



Accelerometer

The accelerometer indicates acceleration along the aircraft's vertical axis. The indicator is calibrated in gravity units or "g's."

The indicator has two pointers; one pointer gives a continuous indication of the loading on the airframe. The other one records the peak positive "g's."

A knob on the unit will reset the peak pointer to the 0 position.



Turn And Slip Indicator

The Turn And Slip combines two instruments in one.

The Turn needle tilts in proportion to the rate of turn. The two lines in the center indicate a 5 degrees turn rate from the center.

The ball in the tube is centered when the aircraft is in trimmed unyawed flight. The ball moves if the aircraft is slipping or skidding.



Angle Of Attack (AOA) Indicator

The angle of attack indicator provides a visual indication of angle of attack, the indicator pointer moves over a scale graded from 0 to 30 units. The AOA value for landing is set at 15 units (see figure). Stall warning is set for 17.5.

NOTE: AOA unit does NOT directly relate to AOA value in degrees. A formula is used to convert from degrees to units.

COMMUNICATIONS AND AUTOMATIC DIRECTION FINDING (ADF)

The RAZBAM model of the T-2 Buckeye differs from the real airplane in the workings of the communication equipment.

The original aircraft had one command radio with an auxiliary receiver. The original command radio had 3,500 frequencies available but unfortunately FSX does not have that many, forcing us to alter the operation to fit FSXs limitations.

COMMAND RADIO CONTROLS



T-2A (T-2J-1-S)
 Communications Panel:
 AN/ARC 27A UHF Set
 AN/ARN 21 Radio Navigation (TACAN)
 AN/ARR 40 UHF Aux Set



T-2B, T-2C, T-2D & T-2E
 Communications Panel
 AN/ARC 159 UHF Set
 AN/ARA 25A ADF
 AN/ARR 40 UHF Aux Set



T-2A (T-2J-1-S) AN/ARC 27A UHF Command Set

Channel Selector (CHAN) - The CHAN selector allows the selection of 20 preset radio frequencies for quick use in the unit. You can select a channel by either left or right clicking on the CHAN knob.

Manual Frequency Selector - The manual frequency selector allows you to manually tune all valid FSX radio frequencies. You can change frequencies up or down by either left or right clicking on the knob.

Radio frequency indicator - The frequency indicator consists of three wheels that are read as follows:

- **Outer wheel marked from 10 to 29:**
Gives the frequency in the 100 to 290 Mhz range.
- **Middle wheel marked from 1 to 0:**
Gives the frequency in the 1 to 10 Mhz range.
- **Inner wheel marked from 1 to 0:**
Gives the frequency in the 0.1 to 0.9 Mhz range.

Mode Selector - The mode selector switch controls the mode of operation of the command set.

- **OFF:** No ADF signal is available.
- **TR:** Radio mode selected. No ADF signal is available.
- **ADF:** ADF Signal is available if the AN/ARR 40 Mode is in CMD/GRD Mode.

Volume (VOL) Switch - In ADF mode it allows to hear the ADF Ident signal.

T-2B, T-2C, T-2D & T-2E AN/ARC 159 UHF Command Set

Channel Selector (CHAN) - The CHAN selector allows the selection of 20 preset radio frequencies for quick use in the unit. You can select a channel by either left or right clicking on the CHAN knob.

Manual Frequency Selectors - The manual frequency selectors allow you to manually tune all valid FSX radio frequencies. You can change frequencies up or down by either left or right clicking on the knobs.

Radio Frequency Indicators - There are four frequency indicators that show the currently selected frequency. Since FSX radios frequencies range is from 118.000 136.975 Mhz the 100 Mhz indicator is not shown. For example if the selected frequency is 121.75 Mhz the indicators will show 2175.

Mode Selector - The mode selector switch controls the mode of operation of the command set.

- **OFF:** No ADF signal is available.
- **TR:** Radio mode selected. No ADF signal is available.
- **ADF:** ADF Signal is available if the AN/ARR 40 Mode is in CMD/GRD Mode.

Volume (VOL) Switch - In ADF mode it allows to hear the ADF Ident signal.




ADF

In the original aircraft there is no way to select an ADF frequency except by selecting it from one of the 20 preset channels. To simplify this operation we included an ADF frequency selector below the Command Radio Set. The frequencies are selected by clicking on the thumbwheel at the side of each frequency indicator.

No ADF signal is available unless either the Command Radio Set or the Auxiliary Radio Set is in ADF mode.

In the T-2B to E models, you must click on the frequency plate to show the ADF frequency selectors.



Frequency Plate



ADF frequency selector

AN/ARR 40 UHF Aux Set (All models)

The AN/ARR 40 UHF receiver is the main ADF receiver. It also works as a secondary UHF transmitter/receiver. There is no way to manually select frequencies in this equipment; you must use the CHAN selector to choose from the 20 presets radio frequencies.

Mode Selector - The mode selector switch controls the mode of operation of the command set.

- **OFF:** The set is unavailable.
- **MAIN:** T/R; AUX: ADF. The Set is in ADF mode while the command set is in radio mode. This is the normal mode of operations.
- **MAIN:** ADF; AUX: CMD. The Set is in radio mode while the command set can be placed in ADF mode. If the command set is not in ADF mode, both radios can be used to receive communications from different frequencies.
- **MAIN:** ADF; AUX:GRD. Works the same as ADF/CMD. There is no GUARD frequency in FSX.





PRESET Channels (All Models)

Since this aircraft makes use of preset radio frequencies stored in 20 channels, we have included a gauge that allows you to save before the start of the flight all the radio frequencies that you will need.



YOU SELECT THIS GAUGE BY CLICKING ON THE VIEW\INSTRUMENTS\RADIO PRESETS MENU

The gauge will appear and you will be able to select the frequencies that you intend to use.

MODE Selector - The mode selector allows you to select which preset section you want to setup. MAIN: Selects the Command Set Preset Channel Memory; AUX: Selects the Auxiliary Receiver Preset Channel Memory; ADF selects the ADF Preset Channel Memory.

Channel (CHAN) Selector - The CHAN selector controls which memory area will be used to store the selected frequency.

	1	2	3	4	5
Radio (Mhz)	100	10	1	0.10	0.01
ADF (Khz)	1000	100	10	1	0.1

Frequency (FREQ) Selectors - The frequency selectors change the value of the selected frequency. The range change if the frequency is for radio communications or ADF.

INVALID Warning Light - The INVALID frequency warning light turns on when the frequency selected is outside the allowed range for FSX. The FSX frequency range for radio communications is from 118.000 - 136.975 Mhz. The frequency range for ADF radio navigation is from 100.0 to 1799.9 KHz. Any value outside these ranges will not be stored.

SAVE Switch - The SAVE switch will save the selected frequency in the chosen channel. It is located below the INVALID light switch.

OPERATION

1. The RADIO CHANNEL PRESELECTOR works only when the aircraft is on the ground with the engines off and the parking brake set. The task of entering the radio frequencies into the system is done by ground crew.
2. Click on the MODE selector until it points to the system you want to set: MAIN, AUX or ADF.
3. Click on the CHAN selector until you get the channel that you want to setup.
4. Click on the FRQ selectors until you get the radio frequency that you want. The INVALID light will come out if the frequency selected won't work in FSX.
5. Click on the SAVE switch to store the frequency in the selected channel.



AIRBORNE TRANSPONDER (IFF/SIF) AN/APX 72 (UNAVAILABLE ON THE T-2A/T-2J 1 S)

The RAZBAM model of the T-2 Buckeye IFF set differs from the original one due to limitations of FSX. Unlike the real aircraft, this model's IFF transponder works only as a General Aviation Transponder so any special IFF/SIF settings are unavailable.

NOTE: The T-2A (T-2J-1-S) does not have either an IFF or GA Transponder.



IFF Control Panel

IFF MODE Switches

They select operating IFF mode. Their functionality is not modeled.

MODE SELECT Knob

Turns ON/OFF the IFF system. Its functionality is not modeled.

IFF MODE 1 Display

Displays MODE 1 IFF Code. The code can be changed by clicking on the thumbwheels located at the right of the numbers.

IFF MODE 3 Display

Displays MODE 3 IFF Code. The GA Transponder code is show in this display. The code can be changed by clicking on the thumbwheels located at the right of each individual number.



AIRCRAFT OPERATING LIMITATIONS

We at RAZBAM have worked to provide you with the most accurate simulation of a real T-2 Buckeye. Because of that, and just like the real aircraft, there are several operating limitations that you must keep in mind to avoid crashing and burning.

Note: The flight model is very close to the real one. Do not exceed these limitations or you will find yourself in real trouble real fast.

CAUTION: THE RISK OF OVERHEATING THE ENGINE IS REAL. PAY CLOSE ATTENTION TO THE EGT GAUGE, ESPECIALLY WHEN USING 100% THROTTLE OR WHEN DIVING. REFRAIN FROM USING POWER DIVES UNLESS ABSOLUTELY NECESSARY. ENGINE DAMAGE WILL OCCUR IF THE OVERTEMPERATURE CONDITION REMAINS TOO LONG.

MAXIMUM PERMISSIBLE AIRSPEEDS

Airspeed485 KIAS from sea level to 9,000 feet
0.85 MACH above 9,000 feet.

Flaps

Normal actuation (in transit)165 KIAS
 Extended165 KIAS

Landing Gear

Normal actuation (in transit)165 KIAS
 Extended165 KIAS

T-2A (T-2-J-1-S)

Westinghouse J34-WE-46/48 ENGINE OPERATIONAL LIMITS

Oil Pressure.....40 - 50 PSI

Hydraulic Pressure3100 PSI

Engine speed

Normal (maximum continuous) ...96.8% RPM

Military (30 minutes).....101% RPM

Overspeed (20 seconds)104% RPM

Exhaust Gas Temperature

Normal (maximum continuous) ...905°C

Military (30 minutes).....960°C

Overtemperature (20 seconds) > .960°C

MAXIMUM OPERATING WEIGHTS

Field Operations

Take off11,528 lbs

Landing9,915 lbs

Arrested landing9,915 lbs

(no tip tank fuel)

Carrier Operations

Catapult11,369 lbs

Arrested Landing9,915 lbs

(no tip tank fuel)





T-2B

Pratt & Whitney J60-P-6 ENGINE OPERATIONAL LIMITS

Oil Pressure.....40 – 50 PSI

Hydraulic Pressure3100 PSI

Engine speed

Normal (maximum continuous) ...96.8% RPM
continuous.

Military (30 minutes).....104.2% RPM

Overspeed (20 seconds)106%

Exhaust Gas Temperature

Normal (maximum continuous) ...577°C

Military (30 minutes).....677°C

Overtemperature (20 seconds) > .677°C

MAXIMUM OPERATING WEIGHTS

Field Operations

Take off13,300 lbs

Landing13,300 lbs

Arrested landing10,400 lbs
(no tip tank fuel)

Carrier Operations

Catapult13,300 lbs

Arrested Landing.....10,400 lbs
(no tip tank fuel)

T-2C, T-2D & T-2E

General Electric J85-GE-4 ENGINE OPERATIONAL LIMITS

Oil Pressure.....40 - 50 PSI

Hydraulic Pressure3100 PSI

Engine speed

Normal (maximum continuous) ...96.8% RPM

Military (30 minutes).....101% RPM

Overspeed (20 seconds)104% RPM

Exhaust Gas Temperature

Normal (maximum continuous) ...718°C

Military (30 minutes).....732°C

Overtemperature (20 seconds) > .732°C

MAXIMUM OPERATING WEIGHTS

Field Operations

Take off14,000 lbs

Landing14,000 lbs

Arrested landing12,445 lbs
(no tip tank fuel)

Carrier Operations

Catapult14,000 lbs

Arrested Landing.....12,000 lbs
(no tip tank fuel)

CAUTION: FOLLOW THESE LIMITATIONS, ESPECIALLY WHEN LANDING. THE AIRCRAFT CAN AND WILL DEPART FROM CONTROLLED FLIGHT IF YOU DON'T FOLLOW THEM.





NAVIGATION/WEAPONS DELIVERY SYSTEM

The Navigation/Weapons Delivery system assists the pilot in navigation and weapons release. The instruments here detailed work as close as possible to the originals.

Note: Several instruments panels are “hidden” by other elements like the throttle, pilot’s joystick and levers. To “clear the clutter” we have set up a switch in the INTERNAL LIGHTS panel to make these elements appear/disappear.



Fig. 1
Normal “Cluttered” view



Fig 2
“Uncluttered” view

TACAN SYSTEM

Although FSX does not have a TACAN system, we at RAZBAM have created one for T-2 Buckeye by using existing VOR stations thanks to a conversion table. There is one caveat, the TACAN system has 126 channels but FSX does not have that many VORs so there are several TACAN channels with invalid VOR frequencies. Otherwise, the TACAN system is fully operational and is able to provide navigational aid to the pilot.

1. **Channel Selector**
Selects operating TACAN channel.
2. **Channel Indicator**
Indicates current TACAN channel.
3. **MODE Selector**
Activates the TACAN and selects operational mode.



To activate the TACAN system you must click on the TACAN MODE selector until it points at T/R. If the selector points to A/A the ILS system will be activated.

There are 126 TACAN Channels available. The TACAN system only has access to the X Band; all Y Band TACAN Channels cannot be used.

To select a TACAN channel you only have to click on the channel selector. If you keep the left button down the channels will cycle faster.

To identify which TACAN channel corresponds to a given VOR frequency you can click on the lid of the map case located



at the right of the seat. A clipboard with a TACAN to VOR conversion table will appear. Clicking either the clipboard or the map case lid will hide the clipboard.

You can also find the TACAN to VOR conversion table in the Appendix. The invalid TACAN channels are identified in that table.



Map Case



TACAN table clipboard

TACAN information is displayed in two gauges located in each instrument panel: The TACAN Course Indicator (TCI) and the Bearing Heading Distance Indicator (BHDI).

TACAN Course Indicator (TCI)



TACAN Course Indicator

The TACAN Course Indicator presents deviation from the inbound or outbound course as selected by the pilot. The Deviation (vertical) Bar moves left or right of center, representing the position of the selected course relative to aircraft position. The Relative Heading Pointer provides a comparison of aircraft magnetic heading with selected course.

The **MARKER** Light will turn on if the TACAN cannot receive the signal from the selected channel.

NOTE: The Glide Slope (horizontal) Bar is inoperative while in TACAN Mode.



Bearing Heading Distance Indicator (BHDI)



Bearing Heading Distance Indicator

The BHDI is comprised of a compass card, a No. 1 and a No. 2 bearing pointer needles and a digital distance indicator.

- The No.1 needle indicates ADF station magnetic bearing when the ADF is active; otherwise it shows Ground Track Heading bearing. If no ADF signal is received while the ADF is active, the needle will point to the North.
- The No. 2 needle indicates TACAN station magnetic bearing when the TACAN is active; otherwise it shows Magnetic Ground Track Heading. If no TACAN signal is received while the TACAN is active, the needle will point to the West.
- The Digital Distance Indicator will show slant range in nautical miles towards the selected TACAN station. Otherwise it will read 0.
- The Compass card will show aircraft magnetic heading.

OPERATION

To operate the TACAN proceed as follows:

1. Click on the TACAN MODE Selector knob until it reads T/R.
2. Select desired TACAN station channel (1 to 126) by clicking on the CHAN selector switch.
3. Check MARKER light to see if a signal is being received. The light must remain off.
4. Check No. 2 bearing pointer needle and verify that it is pointing.
5. Select desired course by clicking on the SET knob.
6. Maneuver the aircraft until the Deviation Bar is centered on the TCI.





ILS SYSTEM

The original T-2 Buckeye does not have an ILS system. Nevertheless we have included one to help during the approaches/landings.

The ILS uses the TACAN panel, the TACAN Course Indicator and the COMMAND SET radio.



TACAN Panel



COMMAND SET
(T-2B to E)

OPERATION

To operate the ILS you must proceed as follows:

1. Click on the TACAN MODE Selector knob until it reads A/A.
2. Select desired ILS frequency by clicking on the frequency selector knobs in the COMMAND SET.
3. Check the TCI, both the Deviation and Glide Slope bars should become active.
4. Maneuver the aircraft until the bars are centered in the TCI.

NOTE: FSX ILS frequency ranges is from 108.000 to 117.975 MHz. The 100 Mhz range value is not displayed. An ILS frequency of 113.45 Mhz will be displayed as 1345.





WEAPONS MANAGEMENT AND DELIVERY


The T-2 Buckeye was designed primarily to be a flight instruction trainer. Nevertheless the aircraft could be configured to carry a limited suite of weapons on two hard points. The T-2D and T-2E are an export version to which an armament package that added four more hard points for a total of six have been installed.

The aircraft could not carry mixed loads on the hard points; all hard point pairs load had to be the same.

- ▶ T-2A, T-2B and T-2C hard point pairs:
1 - 2.
- ▶ T-2D and T-2E hard point pairs:
1 - 6, 2 - 5 and 3 - 4.

WEAPONS STATION CONTROL BOX

The Weapons Station Control Box provides the control for loading weapons into the aircraft pylons.



Weapons Control Station
for the T-2A (T-2J 1S),
T-2B and T-2C



Weapons Control Station for the T-2D and T-2E

OPERATION

The Weapons Station Control panel can be viewed by using FSX's view instruments menu. The Weapons Station Control is only operational under the following conditions: Aircraft is on the ground, Parking brakes are set and engines are completely shut-down (0 % RPM). The point is that only ground personnel have access to the panel and they won't work if the airplane is hot.

The panel is divided in two areas. The top area has a silhouette of the aircraft indicating all the stations available for loading. The bottom area contains the switches that are used to load/unload the aircraft stations.

The first switch selects the type of weapon to be installed. The weapon type codes are as follows:

- ▶ **E:**Empty
- ▶ **G:**Gun pods. Each gun pod carries a Brown-ing M2 HB machine gun with 100 rounds of ammo
- ▶ **B:**Bombs
- ▶ **R:**Rockets
- ▶ **T:**Tow Target (not implemented)

The second switch selects the weapon subtype. The codes are as follows:

- ▶ **E:**Not Applicable
- ▶ **G:**Not Applicable
- ▶ **B:**Bombs:
 - A - BDU 33 practice bombs
 - B - MK 86 practice bomb
 - C - MK 15 practice bomb
 - D - MK 82 (T-2D only) / 500 pounds GP bomb (T-2E only)
- ▶ **R:**Rockets:
 - A - 2.75 in. Mighty Mouse Rocket Package (7 rockets per container).
 - B - 2.75 in. Mighty Mouse Rocket single round launcher.
- ▶ **C:**Zuni Rocket Package (4 rockets per container) (T-2D & T-2E only).
- ▶ **T:** Not Applicable.



The third switch selects the quantity to be installed in the selected hard point pair.

The Hard Point Pair selector knob controls where the weapons will be installed. This knob is only functional for the T-2D & T-2E versions.

The INVALID LOAD light will turn on if a selected weapon suite or quantity is not available for the selected hard point pair.

CREW buttonThis button selects whether the rear crew will be present or not.

FUEL buttonThis button refuels the aircraft.

CLEAN buttonThis button unloads all weapons and the fuel from the tip tanks.

ARMAMENT SYSTEM

The T-2 Buckeye armament system consists of the following items:

- ▶ Gunnery radar
- ▶ Collimated Gunsight
- ▶ Gun camera
- ▶ Armament Panel

For the T-2A, T-2B and T-2C the armament system is an optional package that is only installed if there are weapons loaded in the aircraft hard points. The system is permanently installed in the T-2D and T-2E versions.

The armament panel is only available in the front cockpit.

Weapons delivery (i.e.: dropping bombs) is controlled by the Armament Panel. Weapons delivery is accomplished by either pressing the trigger button on your joystick (usually button 01) or by using the assigned keyboard combination.



ATTENTION

THIS MODEL USES THE CABIN ALERT – SEATBELTS (ON/OFF) EVENT TO SEND A WEAPONS RELEASE SIGNAL. THE ACTUAL RELEASE DROPPABLE OBJECT EVENT IS NOT USED ALTHOUGH IT STILL IS ACTIVE. PLEASE MAP YOUR JOYSTICK TRIGGER BUTTON AND ASSIGNED KEYBOARD COMBINATION TO THE CABIN ALERT – SEATBELTS (ON/OFF) EVENT. FAILURE TO DO SO WILL PREVENT THE ACTIVATION OF THE WEAPONS RELEASE ANIMATIONS.

ARMAMENT PANEL



1. JETTISON Button.
2. TOW TARGET Launch switch.
3. TOW TARGET Release switch.
4. ARMAMENT CONTROL Selector Knob.
5. GUN FIRING Switch.
6. APG 30 RADAR Power Switch.
7. RADAR LOCK ON SENSITIVITY Switch.
8. AFCS ARMAMENT SELECT Switch.
9. SIGHT RETICLE DIMMER Knob.
10. SIGHT RETICLE SELECTOR Knob.
11. CAMERA TEST Switch.
12. RANGE TUNE VOLUME Knob.
13. RADAR RANGE GATES OUT Switch.
14. BOMB ARMING Switch.
15. ARMAMENT MASTER Switch.

Note: The following switches have no modeled functionality:

- a. TOW TARGET Switches
- b. GATES OUT
- c. LOCK ON SENSITIVITY
- d. RANGE TUNE VOLUME
- e. CAMERA TEST
- f. SIGHT RETICLE DIMMER






T-2D & T-2E Armament Panel differences:



1. ARMAMENT CONTROL Selector Knob.
2. BOMB/ROCKET Selector Switch

1. MANUAL RANGE Knob
2. VARIABLE REFLECTOR Knob
3. RANGE METER
4. AFC METER
5. ON TARGET Light
6. TARGET SPAN Lever

GUNSIGHT



T-2A, T-2B & T-2C GUNSIGHT




T-2D & T-2E GUNSIGHT





GUNSIGHT RETICLES



GYRO



FIXED AND GYRO



FIXED

OPERATION

GUNSIGHT

1. Click on the GUNSIGHT SELECTOR Knob to select desired gunsight reticle.
2. Click on the RADAR POWER switch if you want to practice aerial gunnery. The ON TARGET Light will be enabled.
3. If either the GYRO or FIXED AND GYRO sight reticles are selected, you can click on the MANUAL RANGE Knob to adjust the range. The knob is graduated in feet with detents at 600, 900, 1200, 1500 and 2400 feet. The gyro image diamonds will increase or decrease in circumference.
4. Click on the TARGET SPAN Lever to set the estimated span of the target. Available only for GYRO and FIXED AND GYRO sight reticles.

NOTES: The TARGET SPAN Lever is masked by the gunsight camera housing in the T-2A, T-2B and T-2C.

The ON TARGET light will turn on when an aerial target is within the range specified by the MANUAL RANGE Knob.



Copyright © 2010 RAZBAM. This page contains files and work by RAZBAM.



ARMAMENT PANEL

A. BOMBS RELEASE

1. Click the ARMS MASTER Switch to the ON position.
2. Click on the BOMB ARMING switch to select a fuzing type. Left click selects TAIL; right click selects NOSE TAIL.
3. T-2A, T-2B and T-2C Only:
Click on the ARMAMENT CONTROL Knob to select an individual station or both. The Knob must be pointing at the upper hemisphere to release the bombs.
4. T-2D and T E Only:
 - a. Click on the BOMB/ROCKETS Selector switch until it points at BOMBS.
 - b. Click on the ARMAMENT CONTROL Knob to select the stations or station pair that you want to use.

B. ROCKETS RELEASE

1. Click on the ARMS MASTER switch to the ON position.
2. T-2A, T-2B and T-2C Only:
Click on the ARMAMENT CONTROL Knob to select an individual station or both. The Knob must be pointing at the lower hemisphere to release the bombs.
3. T-2D and T E Only:
 - a. Click on the BOMB/ROCKETS Selector switch until it points at ROCKETS.
 - b. Click on the ARMAMENT CONTROL Knob to select the stations or station pair that you want to use.

C. GUN POD

1. Click on the ARMS MASTER switch to the ON position.
2. Click on the ARMAMENT CONTROL Knob until it point at GUNS
3. Click on the GUN FIRING switch until it points at READY

D. JETTISON

1. Check that the ARMS MASTER switch is in the OFF position.
2. Click on the JETTISON button.



TACAN	VOR	TACAN	VOR	TACAN	VOR	TACAN	VOR
CH	Freq	CH	Freq	CH	Freq	CH	Freq
01	134.4	33	109.6	65	133.8	97	115.0
02	134.5	34	109.7	66	133.9	98	115.1
03	134.6	35	109.8	67	134.0	99	115.2
04	134.7	36	109.9	68	134.1	100	115.3
05	134.8	37	110.0	69	134.2	101	115.4
06	134.9	38	110.1	70	112.3	102	115.5
07	135.0	39	110.2	71	112.4	103	115.6
08	135.1	40	110.3	72	112.5	104	115.7
09	135.2	41	110.4	73	112.6	105	115.8
10	135.3	42	110.5	74	112.7	106	115.9
11	135.4	43	110.6	75	112.8	107	116.0
12	135.5	44	110.7	76	112.9	108	116.1
13	135.6	45	110.8	77	113.0	109	116.2
14	135.7	46	110.9	78	113.1	110	116.3
15	135.8	47	111.0	79	113.2	111	116.4
16	135.9	48	111.1	80	113.3	112	116.5
17	108.0	49	111.2	81	113.4	113	116.6
18	108.1	50	111.3	82	113.5	114	116.7
19	108.2	51	111.4	83	113.6	115	116.8
20	108.3	52	111.5	84	113.7	116	116.9
21	108.4	53	111.6	85	113.8	117	117.0
22	108.5	54	111.7	86	113.9	118	117.1
23	108.6	55	111.8	87	114.0	119	117.2

TACAN	VOR	TACAN	VOR	TACAN	VOR	TACAN	VOR
CH	Freq	CH	Freq	CH	Freq	CH	Freq
24	108.7	56	111.9	88	114.1	120	117.3
25	108.8	57	112.0	89	114.2	121	117.4
26	108.9	58	112.1	90	114.3	122	117.5
27	109.0	59	112.2	91	114.4	123	117.6
28	109.1	60	133.3	92	114.5	124	117.7
29	109.2	61	133.4	93	114.6	125	117.8
30	109.3	62	133.5	94	114.7	126	117.9
31	109.4	63	133.6	95	114.8		
32	109.5	64	133.7	96	114.9		





FUNCTIONAL CHECKFLIGHT PROCEDURES

10.1 INTRODUCTION

Functional checkflights are those flights required to determine if the airframe, powerplant, and accessories are functioning in accordance with predetermined requirements while subjected to the operating environment. Functional checkflights have two important and distinct purposes: (1) to ascertain that the aircraft is safe for flight and capable of mission completion when flown by a student or a designated naval aviator and (2) to accurately evaluate the quality of maintenance performed.

10.2 CHECKFLIGHT CREW

The checkflight shall be conducted by a qualified check pilot with the minimum crew required for completion of the mission. The checkpilot shall have the following qualifications:

1. NATOPS qualified in the T-2C aircraft.
2. Designed in writing, by the commanding officer as qualified to perform checkflights.

10.3 CONDITIONS REQUIRING FUNCTIONAL CHECKFLIGHTS

Functional checkflights are required under the following conditions (prior to the release of aircraft for operational use):

- A. After excessive downtime, acceptance check, or as a combination of conditions requiring type B and C checkflights. The complete system check is prefixed by the letter A.
- B. After installation of a new or overhauled engine, major fuel system component replacement, or an engine bleed valve change. Minimum required engine system checks are prefixed by the letter B.
- C. After replacement or adjustment of flight control systems, boost and trim packages, control surface and flap removal, and flap cable lubrication on applicable hose inspections are amongst hoses itoa-

tions requiring a control system check. The minimum items required for a control system check are prefixed by the letter C. The determination that a checkflight is required under circumstances other than those specified is to be made by the maintenance officer, based on the scope of the maintenance accomplished and the effect on maintenance, safety, and the reliability of operation.

Note: Upon replacement or adjustment of an attitude indicator/display, the attitude source, or other related subsystem/component, the functional checkflight may be considered completed by performing only item 38 in lieu of the entire checkflight profile C.




Figure 10-1. Checkflight Profile

10.4 BRIEFING

Prior to each functional checkflight, the checkpilot will be thoroughly briefed by the maintenance officer or his designated representative. Subjects covered shall include: (1) checkflight purpose and requirements, (2) expected results, (3) possible malfunctions, and (4) special corrective action if required.

10.5 PROCEDURES

NATOPS procedures will apply during the entire checkflight unless specific deviation is required by the functional check to record data or ensure proper operation within the approved aircraft envelopes. When training or operational com-



mitments require, combined checkflights and training flights may be made on type C flights, provided all checkflight items are completed prior to normal training maneuvers. Checkflights shall be performed in accordance with OP-NAVINST 4790.2 series, the directives of NAVAIRSYSCOM, or other appropriate authority. The following items provide a detailed description of the functional checks, sequenced in the order in which they should be performed. In order to complete the required checks in the most efficient and logical order, a flight profile has been established for each checkflight condition and identified by the letter corresponding to the purpose for which the checkflight is being flown (i.e. A through C). The applicable letter identifying the profile prefixes checkflight requirements both in the following text and in the functional checkflight checklist (NAVAIR 01-60GAB-IF). Checkflight personnel will familiarize themselves with these requirements prior to the flight.



- | | |
|-----------|--|
| | PREFLIGHT |
| AB | 1.Engines bays.
Check security of lines, quick-disconnects, and doors. |
| AC | 2.Flap operation.
Check for loose panels and stop screw adjustment. |
| AC | 3.Tailhook.
Drop tailhook; check proper operation and pressure indication (raise after ENGINE START). |
| AC | 4.Control surfaces.
Check full throw, cotter pins, and static lines. |
| AC | 5.Trim operation.
Check trim operation, reset to neutral, and observe alignment of tabs with control surfaces. |
| AB | 6.Rear cockpit power control lever release.
Check normal retraction and return to IDLE stop. |
| | PRETAXI |
| AB | 7.Start aircraft on battery (22 volt minimum). |
| AB | 8.EGT inverter. |
| AB | 9.Engine performance.
Record engine instruments at IDLE `pm:
a. EGT - 650°C Maximum. |



- Prior to tuning on generators after engine start, select No. 2 inverter and move power control levers to check for EGT indicating system operation. Reselect No. 1 inverter and turn on generators.
- b. Rpm - 48.5 to 51.5 Percent. Check both engines on battery power only with the No. 2 inverter selected to ensure that only rpm and EGT indicators are functional.
- c. Oil pressure- 5 Psi.
- d. Fuel flow - 400 to 675 Pph.
- e. Hydraulic pressure - 2,885 to 3,215 Psi.
- A** 10. ...External lights.
Check all external lights for operation.

TAXI

- A** 11. ...Brakes.
Check brakes for normal operation.
- A** 12. ...Basic Instrument Checklist.
Check for discrepancies.
- AB** 13. ...Altimeter.
Record altimeter setting.
- AB** 14. ...Runway temperature.
Record runway temperature.

- AB** 15. ...Acceleration check.
Record engine instruments at maximum power prior to brake release:

 - a. EGT - 732°C.
 - b. Rpm - 101.7 Percent.
 - c. PTs.
 - d. Fuel flow.
 - e. Oil pressure.
 - f. ENGINE ANTI-ICE switch.
At 95-percent rpm, check for PTs drop with switch actuation, return to OFF.
- A** 16. ...Landing gear.
Check gear retraction in 10 seconds (maximum).
- CLIMB (AB - 37,000 FEET, C - 12,000 FEET)**
- A** 17.UHF.
Check UHF operation, squelch, preset, and manual.
- AB** 18. ...Engine performance.
Check engine instruments passing 10,000 feet, 270 KIAS:

 - a. Record EGT - 732 °C.
 - b. Record `pm - 101.7 Percent.
 - c. Oil pressure-Check 20 to 65 Psi.
 - d. Fuel flow-Check Split or Fluctuation.



- e. Hydraulic pressure- Check 2,885 to 3,215 Psi.
- f. Record cabin altitude (8,000 feet).
- A** 19. ...Inverters.
Select No. 2 and check for normal indications; return to No. 1.
- A** 20. ...Tacan.
Check tacan and ID-249 for normal operation on several channels.
- AB** 21. ...Boost pump.
To check boost pump operation, pull and reset boost pump circuit breaker individually noting change in amperage loading.
- AB** 22. ...Engine performance.
Check engine instruments, passing 20,000 feet, 240 KIAS:
 - a. Record EGT - 732 °C.
 - b. Record rpm - 101.7 Percent.
 - c. Oil pressure- Check 20 to 65 Psi.
 - d. Fuel flow - Check Split or Fluctuation.
 - e. Hydraulic pressure-Check 2,885 to 3,215 Psi.
 - f. Record cabin altitude (8,000 feet).
 - g. ENGINE ANTI-ICE switch.
Select ON, check for PTs drop, and leave ON.

- AB** 23. ...Fuel dump.
Check fuel dump for equal operation and secure.
- A** 24. ...IFF.
Check AN/APX-64 for normal operation and IDENT.
- A** 25. ...AUXUHF.
Check AN/ARR-%O for normal operation on available channels.
- AB** 26. ...Engine performance.
Check engine instruments, passing 30,000 feet, 215 KIAS:
 - a. Record EGT - 732 °C.
 - b. Record rpm - 101.7 Percent.
 - c. Oil pressure- Check 20 to 65 Psi.
 - d. Fuel flow-check Split or Fluctuation.
 - e. Hydraulic pressure- Check 2,885 to 3,215 Psi.
 - f. Record cabin altitude (11,500 feet).
- AB** 27.AIRSTART switches.
Select ON, check for tone in headset at flight idle; return to OFF.
- A** 28. ...CANOPY DEFROST switch.
Select ON for 10 to 15 seconds; check for sufficient warm airflow.
- A** 29. ...WINDSHIELD ANTI-ICE switch.
Check valve operation and slight pressurization change.
- A** 30. ...PITOT HEATER switch.



Cycle switch; check for variation in amperage loading.

LEVEL (37,000 FEET, 190 KIAS)

AB

31. ...Engine Performance.

- a. Record EGT - 732 °C.
- b. Record rpm - Maximum 9-Percent Decay, 1-Percent Split.
- c. Oil pressure- Check 20 to 65 Psi.
- d. Fuel flow - Check Split or Fluctuation.
- e. Hydraulic pressure-Check 2,885 to 3,215 Psi.
- f. Record cabin altitude (15,500 feet).

AB

32. ...Compressor stall check.

Slow aircraft to 150 KIAS, wings level, advance one power control lever to maximum power.

Retard power control lever; jam accelerate while engine is decelerating. Monitor EGT and airspeed, do not slow below 150K IAS. Repeat procedure with the other power control lever.

DESCENT TO 12,000 FEET

A

33. ...Generator.

Check generator set and loading in normal, operation for maximum 30-ampere split.

AB

34. ...Speedbrake.

- a. Check speedbrake operation for yaw (maximum one-ball-width deflection) or hydraulic pressure malfunction.
- b. Pull speedbrake dump handle. Checks speedbrakes IN. Resets speedbrake dump handle and cycle speedbrakes.

AB

35. ...Engine checks.

- a. Engine shutdown and airstart - Check Individually.
- b. Record jam acceleration, from IDLE to maximum power.
- c. ENGINE ANTI-ICE switch-OFF.

LEVEL - 12,000 FEET

AC

36. ...Boost-off roll check.

- a. Assure that the tip tanks have equal amounts of fuel. Trim for normal balanced flight at 200 KIAS.
- b. Activate trim disk or pull TRIM CONTROL circuit breaker.
- c. Secure HYD BOOST.
- d. Cycle control stick briefly from neutral position to relieve residual hydraulic pressure in the flight control actuators.



- e. Check roll rate not to exceed 5° per second. Avoid exceeding 60° angle of bank.
- f. If roll rate is satisfactory, return to HYD BOOST on and repeat steps by through e at 285 KIAS.
- g. If roll rate exceeds 5° per second, but is controllable, repeat roll check to confirm initial results. Note diction that correction must be made by maintenance personnel to reduce roll rate.
- h. If roll rate exceeds 5° per second and is not controllable, return to BYD BOOST on. Note direction that correction must be made. Stop PMCF at this time, avoid BYD BOOST off operation, and return to field for trim tab adjustment.

AC 37.....control.

- a. Trim - At 15 Units AOA, Trim Aircraft for Balanced Flight Check trim settingsf or control surfaces;t hen accelerateto 340 KIAS andr echeck:
 - (1) RUD - Approximately IN (check balance ball for a maximum of one-ball-width change).

- Continue accelerating to 400 KIAS trim rudder and check:
 - (2) AIL-Approximately IN.
 - (3) ELEV - Approximately 0 to -5 Units Nosedown.
- b. Break turn stall. Take aircraft to recognizable aerodynamics tall.
- c. Check landing gear freefall. Select LDG GEAR override switch to OVERRIDE, and lower landing gear handle.
- d. Angle of attack.
 - (1) Check airspeed at 15 units AOA appropriate for fuel weight. At 1,000 pounds fuel, 93 +/- KIAS, add 4.5 knots per 1,000 pounds additional fuel and 2.5 knots for gun-equipped aircraft.
 - (2) Check indexer lights for proper fast, on-speed, and slow indications and transition.
 - (3) Check rudder pedal shaker actuated at 17-1/2 +/- 1/4 units.
 - (4) Check stall at approximately 19-1/2 +/- 1/2 units.
- e. Landing attitude stall. Take aircraft to recognizable aerodynamics tall and check for yaw, roll, or tuck. If aircraft departs or rolls off early, attempt



- to identify cause by selectively changing position of flaps, speedbrakes, and landing gear.
- f. Approach turn stall.
Take aircraft to recognizable aerodynamics stall and check for unusually yaw, roll, or tuck. If aircraft departs or rolls off early, attempt to identify cause by selectively changing position of flaps, speedbrakes, and landing gear.
- g. Cycle tailhook; check for light out.
- h. WHEELS warning light.
Retract gear hydraulically; adjust power to check WHEELS warning light operation below 95 to 99 percent rpm.
- i. Power-off stall.
Retract flaps and take aircraft to recognizable aerodynamics stall.

NOTE

If unusually yaw, roll, or tuck characteristics are encountered in stalls, consider the suitability of the aircraft for syllabus spins and the possibility of further investigation of aircraft performance during incipient recoveries or spins.

- AC** 38. ...Flight Instruments.
Check flight instruments for normal operation during a loop or other acrobatic maneuvers.
 - a. VGI - Check Proper Tracking and Reversal.
 - b. G-meter - Check for Reasonable Indications.
 - c. BDHI - Check for Proper Tracking and Reversal.
- A** 39. ...RAMEMER.
 - a. Check for pressurization dump in HOLD position.
 - b. Check for airflow after selecting ON for 10 seconds.
- A** 40. ...Pressurization shutoff.
Select pressurization switch to OFF and check for main systems hutoff valve operation.
- A** 41. ...Cockpit temperature control.
Select HOT and COLD (manual) and AUTO modes. Check for proper volume and temperature range.
- A** 42. ...UHF-ADF.
Check UHF-ADF main transceiver ADF function.
- A** 43. ...ICS.
Check all ICS modes and microphone selector positions on control panel and power control lever.

- A** 44. ...Anti-g suit valve.
Manually check operation of modulating valve.


POSTFLIGHT

- AB** 45. ...Landing light.
Cycle landing light and check flush.
- AB** 46. ...Check inside engine bays for security and leaks.






TYPICAL TAKE OFF GROSS WEIGHT 12,500 POUNDS




TYPICAL LANDING PATTERN

GROSS WEIGHT (PAUNDS)	LANDING SPEED (KIAS)	
	FULL FLAPS	
	APPROACH	TOUCH-DOWN
9,000	100	95
10,000	105	100
10,500	110	100
11,000	115	105






CARRIER LANDING PATTERN MIRROR APPROACH




AERIAL GUNNERY PATTERN VIEWED FROM ABOVE





NO THRUST GLIDE DISTANCE AIRPLANE CLEAN - ALL WEIGHT CONFIGURATIONS



BEST GLIDE SPEED
135
KNOTS IAS

WITH THE LANDING GEAR AND FLAPS DOWN AND SPEED BRAKES OUT, THE MAXIMUM GLIDE DISTANCE AND TIME IS APPROXIMATELY 1/3 OF THAT SHOW FOR A CLEAN AIRPLANE.

WITH THE LANDING GEAR AND FLAPS DOWN AND SPEED BRAKES IN, THE MAXIMUM GLIDE DISTANCE AND TIME IS APPROXIMATELY 1/2 OF THAT SHOW FOR A CLEAN AIRPLANE.


EMERGENCY LANDING PATTERN

FOR NO-FLAPS CONDITIONS INCREASE APPROACH AND LANDING SPEED BY 15 KNOTS

TO BE USED FOR:

- PRACTICE PRECAUTIONARY EMERGENCY LANDING
- PRECAUTIONARY EMERGENCY LANDING
- FLAME-OUT LANDING

IN EVENT OF EMERGENCY FUEL STATE, OR THE RELIABILITY OF BOTH ENGINES IS QUESTIONABLE, CARRY OUT A PRECAUTIONARY EMERGENCY LANDING. IF LOSS OF POWER IS EXPERIENCED DURING THE PATTERN, RETRACT SPEED BRAKES AND CONTINUE TO THE APPROACH AT NO-THRUST.



WARNING
EXCEPT WHEN DITCHING, EXTEND LANDING GEAR FOR ALL LANDINGS. ACTUAL EMERGENCY LANDINGS WITH THE GEAR EXTENDED MINIMIZE PILOT INJURY SINCE THE LANDING GEAR ABSORBS THE INITIAL SHOCK OF LANDING IMPACT



Bear's Den



The Convair 201
Learn about how we developed a "What If" aircraft.

[See More](#)

The Bear's Tweets

zuse67
CodingBear

CodingBear I hate it when somebody makes a deal and later retracts himself. #days ago · reply · retweet · favorite

CodingBear At last got a crackberry. 188 days ago · reply · retweet · favorite

CodingBear I hate writing manuals. 186 days ago · reply · retweet · favorite

CodingBear It's a bitch working with one hand I can only type. 282 days ago · reply · retweet · favorite

twiiter
Join the conversation

Prowler's Tweets

Ron Zambrano M
RAZBAM

RAZBAM RAZBAM releases the T-2 Buckeye X! <http://t.co/00u3Rfng>
Complete new model and accurate systems! check it out!
26 days ago · reply · retweet · favorite

RAZBAM RAZBAM Convair F/A-201A Kestrel, RAZBAM SMS <http://t.co/1VCA2qxs>
189 days ago · reply · retweet · favorite

RAZBAM Convair F/A-201A released! you can find it here: <http://t.co/1VGR2qxs>
173 days ago · reply · retweet · favorite

twiiter
Join the conversation

VISITORS: Counter



Fly it Now!

Our Featured Products

[View all](#)



North American T-2 Buckeye ★★★★★

RAZBAM is happy to announce the release of the T-2 Buckeye. A classic aircraft, used to train over 11,000 busy pilots. Another aircraft in our line of "busy cockpit's".

[See More](#)



Convair F/A-201A Kestrel ★★★★★

RAZBAM has brought to FOX the Convair F/A-201A. Multitrole aircraft. This aircraft is the first one in our new "What If" line. The "What-If" line are aircraft that never left the design board.

[See More](#)



LTV A-7 Corsair II ★★★★★

RAZBAM has brought to FOX the Ling-Temco-Vought A-7 Corsair II attack aircraft. This 1st Generation automated aircraft is also the first to use the RAZBAM's Busy Cockpit (tm) concept...

[See More](#)



Convair F-102 Delta Dagger ★★★

The Convair F-102 Delta Dagger is a member of the famed Century Series of US Aircrafts. It was part of the backbone defense of the US against Soviet nuclear bombers...

[See More](#)



Grumman A-6 Intruder ★★★★★

The Grumman A-6 Intruder was a twin jet-engine, mid-wing attack aircraft built in the United States by Grumman Aerospace. In service with the U.S. Navy and U.S. Marine Corps between 1963 and 1977....

[See More](#)



Northrop Grumman EA-6B Prowler ★★★

The Northrop Grumman EA-6B Prowler is a twin-engine, mid-wing electronic warfare aircraft, manufactured by Grumman (now Northrop Grumman) as a modification of the basic A-6 Intruder airframe....

[See More](#)

News & Events [View all](#)

(04/11/11) RAZBAM A-7 Corsair II Vols 1 & 2 Upgrades are available

The upgrades to Volume 1 & 2 of the RAZBAM A-7 Corsair II are available. With these upgrades all our volumes will have the same characteristics.

[See more...](#)

(04/05/11) RAZBAM A-7 Corsair II Vol 3 is Out!

The last volume in the A-7 Corsair II series has been published.

[RAZBAM A-7 Corsair II Page](#)

[RAZBAM A-7 Corsair II Vol. 3 product page](#)

Video Picks [View all](#)



A-7 Corsair II Bomb Test Video

Fresh from our labs. A video from our recent bomb test.

[Watch in 50](#)



A-7 Corsair II Promo Video

The fantastic promo video created by Miraghi0209.

[Watch in 50](#)



F-102 Promo Video

Watch our Delta Dagger take off with full afterburners.

[Watch in 50](#)